

Processing Conditions for Hair Conditioner Base C 25.70 % Organic Ingredients

Converting Hair Conditioner Base C into A Finished Product

1. To a sterilised vessel with a suitable stirrer (preferably with variable speed), lid and preferably with a heater, add the Hair Conditioner Base C.

Please note:

The best type of agitation is likely to have large blades that go close to the edge of the sides of the vessel. Just a small propeller stirrer in the middle of the vessel may not be sufficient.

2. With the stirrer on slow heat the Hair Conditioner Base C to 38 – 40°C. Add organic essential oils as required (typically add 0.2 – 0.5%). Stir for 15 – 30 minutes or until all the oil has fully dispersed.
3. Fill into the required containers.
4. Take sample for microbiological testing both before and after filling

Please note that we do recommend that you carry out tests before manufacturing large batches.

Revision Number 0